




TORQUE ADAPTOR

(AIRBUS 320-321)



Part Number : 460007230

BRAKE RELEASE KIT

(AIRBUS 320-321)



Part Number : 98D32403005001

MLG WHEEL NUT ADAPTOR (AIRBUS 320-321)



Part Number : H47682

PROTECTOR, AXLE NLG (AIRBUS 320-321)



Part Number : J47548

PROTECTOR

(AIRBUS 320-321)



Part Number : F46754-1000

GUIDE CONE-WHEEL (AIRBUS 330)



Part Number : M47381

GUIDE CONE (AIRBUS 330)





Part Number : M47382-100

DISASSEMBLY IMPELLER (AIRBUS 330)



Part Number : MGI74-04

SPANNER-AXLE NUT (AIRBUS 330)



Part Number : 460007011

ADAPTOR **(AIRBUS 330)**



Part Number : R46014

BRAKE GUIDE CONE

(AIRBUS 330)




Part Number : 2558758

SOCKET-AXLE NUT (BOEING 737 CL)



Part Number : F80168-3

AXLE PROTECTOR MLG (BOEING 737 CL)



Part Number : F72913-8

THREAD PROTECTOR MLG (BOEING 737 CL)



Part Number : F72913-11

THREAD PROTECTOR NLG (BOEING 737 CL)





Part Number : F72913-15

NLG SOCKET (BOEING 737 CL)



Part Number :1922

WHEEL/BRAKE REMOVAL INSTALLATION TOOLS (BOEING 737 NG)




Part Number : C32012-13

WHEEL BEARING LOCKNUT SOCKET (BOEING 737 NG)



Part Number : OTC1922

THREAD PROTECTOR MLG (BOEING 737 NG)



Part Number : C32022-18

NLG WRENCH SOCKET (BOEING 737 NG)



Part Number : F80168-1

MLG AXLE PROTECTOR (BOEING 737 NG)



Part Number : C32022-3


MLG SOCKET ASSY (BOEING 737 NG)



Part Number : C32012-13

WRENCH

(BOEING 747)



Part Number : J32032-23

THREAD PROTECTOR (BOEING 747)



Part Number : G32008-2

WRENCH (BOEING 757)



Part Number : B32010-23

SPANNER-NUT NLG (BOEING 757)



Part Number : PI908

THREAD PROTECTOR (BOEING 757)




Part Number : B32010-3

AXLE PROTECTOR NLG (BOEING 757)



Part Number : B32021-1

THREAD PROTECTOR (BOEING 767)



Part Number : J32031-13

AXLE PROTECTOR (BOEING 767)



Part Number :A32097-3

THREAD PROTECTOR ASSY (BOEING 767)



Part Number :A32097-2

WHEEL RETAINING NUT(WRENCH) MLG (BOEING 767)



Part Number :A32012-13

PROTECTOR-AXLE NLG **(BOEING 767)**





Part Number :A32022-1

AXLE PROTECTOR MLG (BOEING 767)



Part Number : A32098-3

AXLE PROTECTOR MLG (BOEING 767)



Part Number :A32098-3

THREAD PROTECTOR (BOEING 777)



Part Number : J32007-2

AXLE NUT WRENCH ASSY (BOEING 777)




Part Number :A32045-114

AXLE, THREAD PROTECTOR MLG NLG (BOEING 777)




Part Number : J32007-1

WRENCH MLG NUT (BOEING 777)




Part Number : J32032-23

WRENCH (BOEING 787)



Part Number : J32032-23

WRENCH - NLG WHEEL RETENTION NUT (BOEING 787)



Part Number : K32022-I

THREAD PROTECTOR ASSY (BOEING 787)



Part Number : J32031-3

NLG WRENCH (BOEING 787)



Part Number : K32022-I

SLEEVE ASSY (BOEING 787)



Part Number : J32032-3

SUPPORT ROD ASSY (BOEING 787)



Part Number : J32032-4

AIRBUS 320-321 WHEEL / BRAKE UNIT REMOVAL INSTALLATION KIT



NO	PART NUMBER	DESCRIPTION
1	Q47316	MAIN GEAR REMOVAL
2	F46754-1000	PROTECTOR AXLE MLG
3	H47682	MAIN GEAR REMOVAL
4	460007230	NLG&MLG PROTECTOR
5	J47549	NOSE GEAR REMOVAL
6	98D32403005001	ADAPTER BRAKE UNIT
7	J47548	PROTECTOR
8	J47779	MAIN GEAR PROTECTOR

Part Number :

BOEING 737 CL WHEEL / BRAKE UNIT REMOVAL INSTALLATION KIT



NO	PART NUMBER	DESCRIPTION
1	1922	B737 CL/NG
2	F72913-11	MLG PTOTECTOR
3	F72913-15	737 CL NLG
4	F72913-8	MAIN GEAR
5	F80168-3	MLG SOCKET
6	N/A	ADAPTER 1/2" - 3/4"
7	N/A	ADAPTER 3/8" - 1/2"

Part Number :

BOEING 737 NG WHEEL / BRAKE UNIT REMOVAL INSTALLATION KIT



NO	PART NUMBER	DESCRIPTION
1	C32012-13	MLG SOCKET
2	C32022-18	MLG THREAD PROTECTOR
3	C32022-3	MLG AXLE PROTECTOR
4	C32022-3	MLG AXLE PROTECTOR
5	1922	SOCKET, AXLE NUT
6	N/A	ADAPTER 1/2" - 3/4"
7	N/A	ADAPTER 3/8" - 1/2"

Part Number :

BOEING 757 WHEEL / BRAKE UNIT REMOVAL INSTALLATION KIT



NO	PART NUMBER	DESCRIPTION
1	B32010-23	MAIN GEAR REMOVAL
2	P1908	NOSE GEAR REMOVAL
3	B32010-3	PROTECTOR AXLE MLG
4	B32021-1	PROTECTOR AXLE NLG

Part Number :

BOEING 767 WHEEL / BRAKE UNIT REMOVAL INSTALLATION KIT



NO	PART NUMBER	DESCRIPTION
1	A32098-3	B767 MLG THREAD PROTECTOR
2	A32012-13	WRENCH - WHEEL RETAINING NUT MLG
3	A32101-2	WRENCH ADAPTER – AXLE NUT NLG
4	A32097-3	B767 NLG THREAD PROTECTOR

Part Number :

AIRBUS 330 WHEEL / BRAKE UNIT REMOVAL INSTALLATION KIT



NO	PART NUMBER	DESCRIPTION
1	2558758	CONE - BRAKE GUIDE
2	M47381	GUIDE CONE-WHEEL
3	460007011	SPANNER-AXLE NUT, MLG
4	M47382-100	GUIDE CONE-WHEEL
5	R46014	ADAPTOR
6	MG174-04	DISASSEMBLY TOOL

Part Number :

BOEING 747-400 WHEEL / BRAKE UNIT REMOVAL INSTALLATION KIT



NO	PART NUMBER	DESCRIPTION
1	G32008-2	THREAD PROTECTOR AXLE MLG&NLG
2	J32032-23	WRENCH WHEEL NUT

Part Number :

BOEING 787 WHEEL / BRAKE UNIT REMOVAL INSTALLATION KIT



NO	PART NUMBER	DESCRIPTION
1	J32032-23	WRENCH WHEEL NUT
2	J32031-3	AXLE PROTECTOR ASSEMBLY
3	K32022-1	NLG WHEEL NUT
4	J32032-4	SUPPORT ROD ASSEMBLY
5	J32032-3	SLEEVE

Part Number :

EMBRAER ERJ190 WHEEL / BRAKE UNIT REMOVAL INSTALLATION KIT



NO	PART NUMBER	DESCRIPTION
1	2370-T158-401	NLG AXLE HEAD PROTECTOR
2	53387-0011	MLG AXLE THREAD PROTECTOR
3		NUT 2.5"
4		NUT 1.5"

Part Number :


BOEING 777 WHEEL / BRAKE UNIT REMOVAL INSTALLATION KIT



NO	PART NUMBER	DESCRIPTION
1	A32045-114	AXLE NUT WRENCH ASSY
2	J32007-3	AXLE PROTECTOR
3	J32032-23	WRENCH WHEEL NUT
4	J32007-2	THREAD PROTECTOR

Part Number :

BOEING 747-800 WHEEL / BRAKE UNIT REMOVAL INSTALLATION KIT



NO	PART NUMBER	DESCRIPTION
1	G32007-8	PROTECTOR AXLE WLG AND BLG
2	G32007-9	PROTECTOR AXLE WLG AND BLG
3	G32039-4	WRENCH ASSY
4	G32007-2	PROTECTOR
5	G32008-1	PROTECTOR AXLE MLG AND NLG
6	G32039-2	SLEEVE ASSY
7	G32039-26	DOOR EXTENDER ASSY

Part Number

TORQUE WRENCHES


LB-IN 0,88-7,08



Part Number : 6973N

TORQUE WRENCHES

LB-FT 30-150



Part Number : 7454-18

TORQUE WRENCHES

LB-FT .74-3.7/LB-IN 8.9-44.3



Part Number : 7455-5

TORQUE WRENCHES

LB-FT 2.2-11.1/LB-IN 26.5-132.8



Part Number : 7455-15

TORQUE WRENCHES

LB-FT 3-14.8/LB-IN 35.4-177



Part Number : 7455-20

TORQUE WRENCHES

LB-FT 0.84-4.15/LB-IN 10-50



Part Number : 6060A

TORQUE WRENCHES

LB-FT 0.33-6.66/LB-IN 4-80



Part Number :TASI4H09

TORQUE WRENCHES

LB-FT 0.33-6.66/LB-IN 4-80



Part Number : TASI4H09

TORQUE WRENCHES


LB-FT 0.6-3/LB-IN 8-40



Part Number : QDRIVER4

TORQUE WRENCHES

LB-FT 0.33-6.66/LB-IN 4-80



Part Number : 7454-18

TORQUE WRENCHES

LB-FT 0.67-3.67/LB-IN 8-44



Part Number : 4549-00

TORQUE WRENCHES

LB-FT 30-150/LB-IN 360-1800



Part Number : 4550-20

TORQUE WRENCHES

LB-FT 44-220/LB-IN 528-2640



Part Number : 4550-30

TORQUE WRENCHES

LB-FT | 6.6-71.9/LB-IN | 99-863



Part Number : 4549-02

TORQUE WRENCHES

LB-FT 30-145/LB-IN 360-1740



Part Number : 730/20

TORQUE WRENCHES

LB-FT | 18-590/LB-IN | 416-7080



Part Number : 730N/80

TORQUE WRENCHES


LB-FT 18-95/LB-IN 225-1150



Part Number 700A12

TORQUE WRENCHES

LB-FT 1.5-15/LB-IN 20-180



Part Number : 730NA/2

TORQUE WRENCHES

LB-FT 50-220/LB-IN 600-2640



Part Number : 721/30

TORQUE WRENCHES

LB-FT 2.5-12.5/LB-IN 30-150



Part Number : 745418

TORQUE WRENCHES

LB-FT 16-72/LB-IN 192-864



Part Number : 7455-200

TORQUE WRENCHES


LB-FT 16-83/LB-IN 200-1000



Part Number : 4550-20

TORQUE WRENCHES

LB-FT 37-145/LB-IN 444-1740



Part Number : 7455-200

TORQUE WRENCHES

LB-FT 2.5-12.5/LB-IN 30-150



Part Number : 7454-18

TORQUE WRENCHES

LB-FT 83-359.6/LB-IN 996-4315



Part Number : 7455-500

TORQUE WRENCHES


LB-FT 83-359/LB-IN 885-4425



Part Number : 7455-500

TORQUE WRENCHES


LB-FT 0.9-3.5/LB-IN 11-42



Part Number : 7455-5

TORQUE WRENCHES

LB-FT 50-250/LB-IN 602-3009



Part Number : 7455-340

TORQUE WRENCHES

LB-FT 30-145/LB-IN 354-1770



Part Number : 7455-300

TORQUE WRENCHES

LB-FT 83/LB-IN 885-4425



Part Number : 7455-500

TORQUE WRENCHES


LB-FT 184-701/LB-IN 2207-8412



Part Number : 7455-1000

TORQUE WRENCHES

LB-FT 0.6-3/LB-IN 8-40



Part Number : QDRIVER4

TORQUE WRENCHES

LB-FT | 18-590/LB-IN | 416-7080



Part Number : 7455-1000

TORQUE WRENCHES

10CNM - 80CNM / 0.89IN.LB - 7IN.LB



Part Number : 6973N

TORQUE WRENCHES

0,9-3,5 LB.FT. / 11 - 42 IN.LB



Part Number : 7455-5

**ADAPTOR-DRIVE,SLAT
(MANUEL FLAP GEAR BOX DRIVER)
A318-319-320-321**



Part Number : 98D27804001000

INSERTION TOOL-PIN, OXYGEN GENERATOR



Part Number : 995022

PIN BY-PASS TOW NLG A319/A320/A321/A330/A340



Part Number : D23156000

TOOL JAMMING SIMULATION



Part Number : OUI90857

GUIDE PIN-OIL SCAVENGE FILTER



Part Number : IAEIFI0082

TOOL, SEAL FITTING-MAGNETIC PLUG LUBE UNIT



Part Number : 856A2629G01

WRENCH




Part Number : IAE1R18003

BULLENT LOCATING MLG PIVOT BOLT **(A320/A330)**



Part Number : 98D32109005000

TOOL SET SEAL FITTING AGB TGB.



Part Number : 856A2794G01

TOOL-MANUAL CRANKING STOP,THS ACTUATOR



Part number : OUI45920 // OUI45409

CAP



Part Number : ABS0395C6-32

THREAD PROTECTOR SET



Part Number : 98A4910750400I

JACK ADAPTER-FUSELAGE



Part Number : 98D07103500000

WRENCH, REMOVAL - SLIDING WINDOW OF LUCAS AND PPG




Part Number : 98D56103002000&98D56103002201

TOOL-RELEASE,POB



Part Number : OUI90844

PIN-SETTING



Part Number : 98D27504031000

TOOL-OIL FILLING,THS ACTUATOR



Part Number : OUI90364

RING HAMMERED



Part Number : S48515

ADAPTER VENT A320



Part Number : 98A28007570000

TOOL-OIL FILLING,THS ACTUATOR



Part Number : OUI90363

AOA SENSOR TOOL



Part Number : 97D34103000000

LOCKING DEVICE - FLAP DRIVE SHAFT




Part Number : WAS35287

WRENCH GROOVE NUT



Part Number : 98F551090010000

VBV DRIVE RATCHET



Part Number : 856A250IG01

POST-ASSEMBLY



Part Number : 460005171-95

TOOL-HOLDING



Part Number : 460006437

WIRE SPOON STAINLESS STEEL



Part Number : MDA-3792

WIRE HARNESS SPOON




Part Number :WHS-I

GAUGE-BAYONET SLOT WEAR





Part Number : IAEIR19313

LOCK T.E FLAP POWER DRIVE UNIT




Part Number : B27008-I

INSERT -EXTRACT TOOL



Part Number : CTA-0161

LOCKPIN-NOSE GEAR TOWING LEVER B757




Part Number : A09003-2

DIGITAL PROTRACTOR



Part Number : 2173-360

LOCK ASSEMBLY-FLIGHT CONTROLS




Part Number : F80049-66

PIN LOCKOUT L.E.CRUISE DEPRESSURIZATION VALVE




Part Number : C27038-6

LOCK ASSEMBLY-FLIGHT CONTROLS



Part Number : F80049-65

CFM56 T/R BY PASS PIN A320-321



Part Number : HIX3008


TORQUE ADAPTER TEST LATCH DOOR ENG.



Part Number : RSEI234

COVER-STATIC PROBE

A3I8/A3I9/A320



Part Number : 98DI0103500042

PULLER ASSY -SEALING CORD

ALL AIRBUS



Part Number : 98A25207503000

FUEL SAMPLING EQUIPMENT


ALL BOEING



Part Number : AI200I-14

STARTER VALVE DRIVE EXTENSION EQUIPMENT

B767 747-100-200-300-400



Part Number : G71021-16


ACTUATOR/DEACTUATOR SET-PROXIMITY SENSOR ALL 737



Part Number :A27092-8-758-01

GROUND LOCK SLEEVE


A319-320-320 A330 A340 A380



Part Number : DRT68923

COLLAR-SAFETY, SPOILER


A319-320-320 A330 A340 A380



Part Number : 98D27604000000


LOCK-STAB TRIM WHEEL

A319-320-320 A330 A340 A380



Part Number : 98D27403500000

LOAD APPLICATION TOOL ELEVATOR ALL AIRBUS



Part Number : 98D27303000001

ADAPTOR-WATER DRAIN ACT

A318-319-320-321



Part Number : 98D28108293000

KEY MAINTENANCE SPOILER

A320-321



Part Number : 98D27603002000

CLEANER KIT PITOT PROBE

ALL AIRBUS



Part Number : 98D34I0300400I

PURGING TOOL



Part Number : 97A28002 || 7002

FLUSHING TOOL PITOT PROBE

ALL AIRBUS



Part Number : 98F34103003000

ADAPTER PITOT PNEUMATIC CLEANER

ALL AIRBUS



Part Number : 98D34I03003000

GROUND LOCK SLEEVE



P/N : 460005835

FUEL PUMP EXTRACTOR

A320/A321



Part Number : 558-I-05903

FUEL SAMPLE UNIT



Part Number : AGE-04280-40I

REVERSE PUMP



Part Number : C78005-26

HYDRAULIC FLUID DISPENSER



Part Number : ERM001

HAND HELD REOILING PUMP HYDRAULIC



Part Number : 7170


SAFETY DEVICE – RAT

A320-321




Part Number : 98D29208246001

COLLAR-DEPTH ACTUATOR



Part Number : 98D27309009004

THRUST REVERSER ACTUATOR B737



Part Number : C78023-2&C78023-1

FLAP/SLAT LOCKING ZERO TOOL

A318-319-320-321



Part Number : 98D27803500001


DISPACTH EQUIPMENT

B747-100-200-300-400



Part Number : G29003-8

SAFETY PIN - SLIDE ARMING



Part Number : 98D52103500000

PITOT COVER

B747-100-200-300-400 B767 B777



Part Number : KPC3-825-8

PITOT COVER

A300/A320/A330/A340



Part Number : KPC4-480-325

ANGLE OF ATTACK SENSOR-COVER

A320



Part Number : 98A10001500000

COVER PROTECTION-SENSOR TAT



Part Number : 98FI000I003000

RIG PIN HPC VANE CRANK


A320



Part Number : IAEIRI8254

PIN RIGGING


A330/A340



Part Number : 98F272075 | 5000

SAFETY PIN-NLG DOOR

A320



Part Number : 98D32203502000

PIN RIGGING

A3I8-3I9-320-32I



Part Number : IAEIR18282

PIN-LOCKING

A330/340



Part Number : 98F272075 | 6000

BLIND PLUG



Part Number : OUI45506

COVER-STATIC PROBE

A3I8/A3I9/A320



Part Number : 98DI0I0350000I

BULLET SEAL



Part Number : SI606090872

FLAG ASSEMBLY LOCKING HOOK LATCH

A320-321



Part Number : HA2273-I

PORTABLE TOOL BOX



S.No	Ürün Kodu	Ürün Spesifikasyonları
1	696EX-04	¼ DRIVE EXTENSION
2	696EX-06	¼ DRIVE EXTENSION
3	696EX-02	¼ DRIVE EXTENSION
4	6950	RATCHET WRENCH
5	36-797	¼ SINGLE RATCHETING BIT WRENCH
6	1320RZ	¼ AND 9/16 RATCHETING WRENCH
7	1320RZ	3/8 AND 7/16 RATCHETING WRENCH
8	1320RZ	¼ AND 5/16 RATCHETING WRENCH
9	5515T	TELESCOPIC MIRROR
10	A6700DZ	SOCKET 9/16
11		SOCKET 1/2

12	A6700DZ	SOCKET 7/16
13	A6700DZ	SOCKET 3/8
14	A6700DZ	SOCKET 11/32
15	A6700DZ	SOCKET 5/16
16	A6700DZ	SOCKET 9/32
17	A6700DZ	SOCKET 1/4
18	A6700DZ	SOCKET 7/32
19	A6700DZ	SOCKET 3/16
20	A6700DZ	SOCKET ¼ TO ¼ ALLEN
21	AWF9K	HEX KEY SET
22	1Z	COMBINATION WRENCH 9/16
23	1Z	COMBINATION WRENCH ¼
24	1Z	COMBINATION WRENCH 3/8
25	1Z	COMBINATION WRENCH 11/32
26	1Z	COMBINATION WRENCH 5/16
27	1Z	COMBINATION WRENCH 9/32
28	1Z	COMBINATION WRENCH 1/4
29	1Z	COMBINATION WRENCH 7/32
30	1Z	COMBINATION WRENCH 3/16
31	1162N-1/2	LENGTH METER

Part Number :

BIG TOOL BOX



SHELF 1



SHELF 2



SHELF 3



SHELF 4

Part Number :

BIG TOOL BOX



SHELF 5



SHELF 6



SHELF 7







SHELF 8

Part Number :



BIG TOOL BOX

[illegible]

AXLE JACK (10 T)



Part Number : MK-05

AXLE JACK (45 T)



Part Number : MK-04

AXLE JACK (60 T)



Part Number : MK-02

AXLE JACK (90 T)



Part Number : MK-03

DOLLY (WHEEL/BRAKE CHANGER)



Part Number : BH8AC3-600

TAP DIE SUPER SET 39 PCS (DRILL)



Part Number : 2PI2558-25914

SCREW KNOCKER (VİDA KURTARICI)



CABLE TIE TOOL (TENSION CONTROLLED)



Part Number : PANDUIT GTS-E

THREAD CUTTING TOOL SET - DIES AND TAPS



Part Number : I460Z/2

PULLER MLG BRAKE

B777-200/300 B787



Part Number : J32012-18

ADAPTER RR FWD ASSY

AIRBUS A320-321



Part Number : 98F71201001110

STRUT INFLATION TOOL



Part Number : F70200-I

TIRE INFLATION TOOL



Part Number : F70199-52

LARGE AND STANDART BORE CLIPS (BÜYÜK KÜÇÜK SİBOB DÖNÜŞTÜRÜCÜ)



Part Number :

CREW OXYGEN REMOVAL INSTALLATION KIT



NO	PART NUMBER	DESCRIPTION
1	-	10" ADJUSTABLE WRENCH
2	-	SAFETY WIREPLIERS
3	-	RATCHET
4	-	1" COMBINE WRENCH
5	-	7/8" COMBINE WRENCH
6	-	3/4" COMBINE WRENCH
7	-	5/8" COMBINE WRENCH
8	-	9/16" COMBINE WRENCH
9	-	5/16" COMBINE WRENCH
10	-	3/8" DRIVE EXTENSION
11	-	7/16" DEEP SOCKET

Part Number :

WHEEL/BRAKE UNIT REMOVAL INSTALLATION KIT



NO	PART NUMBER	DESCRIPTION
1	MS20995C32	LOCK WIRE 0,032"
2	-	ADAPTER ¾" TO ½"
3	-	ADAPTER ½" TO ¾"
4	-	3/8" DRIVE 15CM EXTENSION BAR
5	-	DIRIVER SPIDER 3/8"
6	T72	RATCHED ¼"
7	J6931	3/8" DRIVE ¼" HEX POWER BIT HOLDER
8	-	3/8" DRIVE 3" EXTENSION BAR
9	-	3/8" DRIVE 13/16" DEEP SOCKET
10	-	3/8" DRIVE ¾" DEEP SOCKET
11	-	3/8" DRIVE 7/16" DEEP SOCKET
12	-	¼" DRIVE 3/8" DEEP SOCKET
13	-	3/8" DRIVE ¾" SOCKET
14	RB-810DH	¼" AND 5/16" FLAT RATCHETING WRENCH
15	RB-1214DH	3/8" AND 7/16" FLAT RATCHETING WRENCH
16	BE-9755	ALLEN SET
17	-	FLAT SCREWDRIVER
18	-	PLASTIC HAMMER
19	-	RATCHETING SCREWDRIVER
20	11-992	RATCHED 3/8"
21	25-214	7/16" COMBINE RANCH
22	-	SAFFETY WIRING PLIERS
23	-	ADAPTER 1/2 Fx3/8M

Part Number :

CIRCUIT BREAKER LOCKOUT RINGS AND TAGS



Part Number : PE7014-SERIES

CIRCUIT BREAKER LOCKOUT RING



Part Number : S4933959-50I RED

STRUT SUPPORT-SPOILER 2,3,4,



Part Number : 98D27604001000

PIN-RIGGING



Part Number : 98D27207546000

INSTALLATION TOOL-FRONT WINDOW PANELS



Part Number :98D56I0300I000

FASTENER REMOVAL TOOL



Part Number :98A53003500000

FASTENER REMOVAL TOOL



Part Number :98A53003500001

AOA COVER



Part Number :98A10001500000

COVER PITOT PROBE



Part Number :98A10001005000

TAT PROBE COVER



Part Number :98A10001013000

PITOT COVER



Part Number :KPC3-825-8

COVER PROTECTION-SENSOR TAT



Part Number :98F10001003000

PITOT COVER



Part Number :KPC4-480-325

PITOT COVER



Part Number :KPC4-480-325

COVER PROTECTION-SENSOR TAT



Part Number :98FI000I003000

COVER AOA SENSOR



Part Number :98D10003003000

ICE DETECTION PROBE COVER



Part Number :98DI0103501000

WIRE TWISTER/CUTTER, REVERSIBLE, .051" CAP, 10-1/2



Part Number :RWVTP9

CAN OPENER



Part Number :N/A



RATCHETING SCREWDRIVER



Part Number :808050L

ADAPTER RR FWD ASSY



Part Number :98F71201001110

SOLDERING IRON



Part Number :30-80W

3M SCOTCH - WELD EPX II DISPENSER



Part Number :DMA50

WATER DRAIN PURGER



Part Number :98A28104000000

CRIMPING TOOL KIT



S.No	Ürün Kodu	Ürün Spesifikasyonları	Kayıp Ürün
1	MS24256R16	REMOVAL TOOL	
2	M81969/19-07	REMOVAL TOOL	
3	M81969/17-09	INSTALLINGN TOOL	
4	M81969/17-03	INSTALLINGN TOOL	
5	M22520/7-12	CRIMP TOOL	
6	M22520/2-06	CRIMP TOOL	
7	M22520/2-09	CRIMP TOOL	
8	019-0249-000	SOCKET CONTACT	
9	CTA0165	SOCKET CONTACT	
10	M22520/7-01	CRIMP TOOL	
11	CTJ-R06	REMOVAL TOOL/CONFORMS TO AS81714/69-01	
12	MDA-3792	WIRE SPOON STAINLESS STEEL	
13	WHS-1	WIRE HARNESS SPOON	
14	CTA-0166	PIN CONTACT	

Part Number :86-20, CTJ-R06,WHS-IDRK20A, DRK16, CTA-1160,


HEAVY DUTY LEVER RIVET TOOL



S.No	Ürün Kodu	Ürün Spesifikasyonları	Kayıp Ürün
1	1468-M10	HEAVY DUTY LEVER RIVET TOOL	
2	1468-10M4	NUT RIVETER INSERTS (M4)	
3	1468-10M5	NUT RIVETER INSERTS (M5)	
4	1468-10M6	NUT RIVETER INSERTS (M6)	
5	1468-10M8	NUT RIVETER INSERTS (M8)	
6	1468-10M10	NUT RIVETER INSERTS (M10)	


Part Number : I468-M10

LOAD APPLICATION TOOL ELEVATOR



Part Number :98D27303000001

ASSY GAUGE PDU ROLLER WEAR



Part Number :ES750-5I

ADAPTER WRENCH SUMP DRAIN VALVE



Part Number :4MIT65B00772


KEY MAINTENANCE SPOILER



Part Number :98D27603002000



TAP WRENCHES WITH RATCHET



Part Number :N/A

STUD EXTRACTOR SET



Part Number :BAHCO 1418S

MULTI SPLINE EXTRACTOR SET




Part Number :BAHCO BWMSP15



REAMERS SET (RAYBALAMA SETi) - FRACTION SET



Part Number :BAHCO BWMSP15



40 PCS TORX ALLEN AND XZN BIT SET



Part Number :N/A

LUMINANCE METER



Part Number :LS-160

PUSH PULL (FORCE GAUGE) 0- 500 N 0-50 KG



Part Number :N/A

AOA SENSOR TOOL



Part Number :97D34103000000

HAND RIVETER G800CMR - INSTALLATION KIT



Part Number :G800CMR

CHECK TOOL (ANALOG)- AILERON ELEVATOR RUDDER



Part Number :98D27303003001

FLUID DISPENSER 5 GALLON (L/G STRUT SERVICE CART)



Part Number :PF5348I-9P

LOCKING PIN

LOCKING PIN



Part Number :A29002-6

INSTALLER LOCKPIN REMOVE TOOL



Part Number :A32015-9